




# Compaq Mini 110 RAM Replacement

Remove RAM

Written By: alea



## INTRODUCTION

Access your RAM and install a new one if you'd like.



### TOOLS:


- [Phillips #0 Screwdriver](#) (1)



### PARTS:


- [PC2-5300 1 GB RAM Chip](#) (1)
- [PC2-5300 2 GB RAM Chip](#) (1)

## Step 1 — RAM



- Find and remove the two screws on the bottom of your Compaq Mini covering the memory compartment.
- ⓘ Note that the screws are attached to the panel.

## Step 2



- Push out side tabs.

To reassemble your device(possibly install a new RAM), follow these instructions in reverse order.

This document was last generated on 2017-08-11 01:25:37 PM.